


JAZZ SC



JAZZ FX



JAZZ CHROME



OPTIONAL LED











Legenda  
Key  
Légende  
Zeichenerklärung  
Leyenda


a: alzata  
a: riser  
a: Hauteur  
a: Tritthöhe/Steigung  
a: Contrahuella

P: pedata  
P: step  
P: giron  
P: Trittfläche  
P: huella


G: gradino  
G: tread  
G: Marche  
G: Stufe  
G: Peldano

H: altezza  
H: high  
H: Hauteur  
H: Hoehe  
H: Altura








G10	G11	G12	G13	G14	G15	G16	G17	G18
h	h	h	h	h	h	h	h	h
1905	2075	2245	2415	2585	2755	2925	3095	3265
2555	2790	3025	3260	3495	3730	3965	4200	4435







$a$	$h$	$h$	$h$	$h$	$h$	$h$	$h$	$h$	$h$	$h$	$h$	$h$	$h$
	G3	G4	G5	G6	G7	G8	G9	G10	G11	G12	G13	G14	G15
175	175	350	525	700	875	1050	1225	1400	1575	1750	1925	2100	2275
180	180	360	540	720	900	1080	1260	1440	1620	1800	1980	2160	2340
185	185	370	555	740	925	1110	1295	1480	1665	1850	2035	2220	2405
190	190	380	570	760	950	1140	1330	1520	1710	1900	2090	2280	2470
195	195	390	585	780	975	1170	1365	1560	1755	1950	2145	2340	2535
200	200	400	600	800	1000	1200	1400	1600	1800	2000	2200	2400	2600
205	205	410	615	820	1025	1230	1435	1640	1845	2050	2255	2460	2665
210	210	420	630	840	1050	1260	1470	1680	1890	2100	2310	2520	2730
215	215	430	645	860	1075	1290	1505	1720	1935	2150	2365	2580	2795
220	220	440	660	880	1100	1320	1540	1760	1980	2200	2420	2640	2860
225	225	450	675	900	1125	1350	1575	1800	2025	2250	2475	2700	2925
230	230	460	690	920	1150	1380	1610	1840	2070	2300	2530	2760	2990



SC



**CHROME**



JAZZ FX

